

# teasmade®

By Swan



We love  
what we do



we're proud  
of our quality

Help line: 0871 200 0003



Model: STM201N

v1.5



**When using any electrical appliance, basic safety precautions should always be followed including the following:**

- Always ensure that the voltage on the rating label corresponds to the mains voltage in your home
- Incorrect operation and improper use can damage the appliance and cause injury to the user.
- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by the manufacturer or qualified person in order to avoid an electrical hazard.
- Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by the manufacturer or qualified person in order to avoid an electrical hazard.
- Do not use the appliance if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent.
- Never immerse the unit in water or any other liquid for cleaning purposes.
- Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance from the mains. Always unplug the unit when not in use, before



## IMPORTANT INFORMATION - RETAIN FOR FUTURE USE

cleaning or when adding or removing parts.

- The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
- Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled on inadvertently.
- Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
- Do not use the appliance on a gas or electric cooking top or over or near an open flame.
- Use of an extension cord with this appliance is not recommended. However, if it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals or tripped over.
- This appliance is not suitable for outdoor use. Do not use the appliance for anything other than its intended use.
- Do not carry the appliance by the power cord.
- Do not leave the appliance unattended during use. Always unplug the unit when not in use or before cleaning.
- Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
- Ensure that the unit is switched off after use.
- The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorised personnel.



## IMPORTANT INFORMATION - RETAIN FOR FUTURE USE

- In case of technical problems, switch off the product and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentions precautions and instructions, could affect the safe operation of this product.
- Your appliance must never be switched on through an external timer or any kind of separate remote control system
- **DO NOT OVER-FILL THIS PRODUCT. DO NOT IMMERSE IN WATER**
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas, in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
- **PLEASE DO NOT ALLOW WATER TO SIT IN THE TANK FOR MORE THAN 2 DAYS AS IT COULD GO STALE AND CAUSE AN UNPLEASANT TASTE.**



## INTRODUCTION

Thank you for purchasing this Swan TEASMADE. With this iconic product, you are joining a unique group of people – going back some 70 years or more – who just have to be woken with a nice, hot cup of tea in the morning – and who can blame you. Even if tea isn't your thing and you prefer a cup of [that new fangled] coffee in the morning, not to worry. This modern, 21st century TEASMADE can make coffee too! But you can't get the Internet on it – just yet.

Please read all the instructions carefully before using your Swan TEASMADE



## HOW TO USE

Before first use, remove all packaging

It is important to ensure the correct plug adaptor is used when operating in a country not using the UK 13 Amp socket system. If in doubt, consult a qualified electrician.

- Do not remove the teapot from the base during the filling cycle as scolding water will be ejected.
- After filling the tank, ensure the cap is properly secured. Do not open the cap during the boiling cycle
- After the tea making cycle is complete, wait a few minutes before removing the filler cap as it will be hot.
- Fill the ceramic jug with water to 1" [25mm] below top.
- Open the lid and remove the tank cap by turning it anti-clockwise
- Pour the water from the jug into the tank and replace the tank cap by turning it clockwise.
- Place the ceramic jug back on it's stand on the TEASMADE, ensuring that it is resting firmly against the safety switch
- Press the TEA NOW button and wait
- In a few minutes the water in the tank will boil and be ejected into the pot. You will hear the traditional TEASMADE woosh! as the water is ejected from the tank into the ceramic pot.
- Once this process is complete, discard the water from the pot
- Your TEASMADE is now clean and ready to use.

### SETTING THE CLOCK

Remove the lid from the Teasmade. There are 2 adjustment knobs. One is to set the clock, the other is to set the alarm. Set the clock first then set the alarm. Note: The clock adjustment knob needs to be pressed down and turned.

### ALARM WITH TEA BUTTON

This button overrides the ON setting of the ALARM ONLY function.

This button has 3 settings:

- SET (for Tea+Alarm)
- OFF (for no function)
- TEA NOW (starts the tea making process on pressing if the tank is filled and the jug is in position)
- In the ON position, tea making will start at selected alarm time.
- 

### ALARM ONLY BUTTON

Set Alarm with Tea button to OFF position.

Use this button when the tea making function is not required. This button has 3 settings:

- SET (for Alarm only)
- OFF (no function)



## HOW TO USE

- SNOOZE (alarm will resound after about 4 minutes)
- Snooze can still be set while alarm is sounding.

### TEA WITH ALARM

Use the jug to fill the tank (do not over-fill). Put Teabags (or required amount of coffee) into the empty jug a place in the jug dock ensuring that the safety switch is pressed.

Put the ALARM+TEA button into the ON position. The tea making process will start at selected alarm time before the alarm sounds. This setting will override the ON setting of Alarm Only function.

### CLOCK LIGHT DIMMER

Remove the lid to find the clock light dimmer control. Adjust for best night time conditions.

### CLEANING & MAINTENANCE

Ensure the product is unplugged from the mains and completely cooled before cleaning. The pot should be cleaned daily with warm soapy water, then rinsed with clean water. Do not leave water in the tank for long periods. Wait until the product has cooled before emptying the tank. The outside of the unit can be cleaned with a soft cloth moistened with a mild detergent solution.

**DO NOT USE CHEMICAL OR ABRASIVE CLEANERS. DO NOT IMMERSE THE UNIT IN WATER.**

### DESCALING

Excessive lime scale build-up will hurt your precious TEASMADE! It is important to de-scale the product regularly in order to maintain best performance. Use a good de-scaling agent available from most supermarkets. Fill the tank using the pot and include the de-scaling agent. LEAVE THE FILLER CAP OFF on this occasion. Place the empty pot on it's stand, ensuring it is in contact with the safety switch. Press the TEA NOW button. The water in the tank will boil. Note: With the filler cap off there will be an increased amount of steam so be careful. Once the water in the tank is boiling, press the TEA NOW button to switch it off.

Carefully replace the filler cap and press the TEA NOW button once again. The water will be ejected into the pot. This will de-scale all the pipes and tubes inside the TEASMADE. Once de-scaling is complete, allow the unit to cool and rinse the tank and pot in clean water.



## TECHNICAL DATA

Description: Retro Teasmade Model: STM201N

Rating: 230-240V AC 50Hz 780-850 Watts

### SPARE PARTS REFERENCES:

STM100-01: Ceramic pot



## WARRANTY

This product is guaranteed for 2 years from the date of original purchase. If any defect arises due to faulty materials of workmanship the faulty products must be returned to the place of purchase. Refunds or replacement is at the discretion of the store.

### The following conditions apply:

- The product must be returned to the retailer with proof of purchase.
- The product must be installed and used in accordance with the instructions contained in this instruction guide.
- It must be used only for domestic purposes.
- It does not cover wear and tear, damage, misuse or consumable parts.
- Swan Products Ltd has limited liability for incidental or consequential loss or damage.
- This guarantee is valid in the UK and Eire Only.



## DISPOSAL OF UNIT

Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately. Please visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk) or [www.recyclenow.co.uk](http://www.recyclenow.co.uk) for access to information about the recycling of electrical items. Please visit [www.weeeireland.ie](http://www.weeeireland.ie) for access to information about the recycling of electrical items purchased in Ireland. The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill. Please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.



## BS PLUG

The wires in the mains lead are coloured in accordance with the following code:

|              |         |
|--------------|---------|
| BLUE         | NEUTRAL |
| BROWN        | LIVE    |
| GREEN/YELLOW | EARTH   |

As the colours of the wire in the mains lead of this appliance may not correspond with the colour markings identifying the terminals on your plug, proceed as follows: The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured red. The wire which is coloured GREEN/YELLOW must be connected to the terminal which is marked with the letter E or [earth symbol] and is coloured GREEN or GREEN/YELLOW.

WARNING: THIS APPLIANCE MUST BE EARTHED



[www.swan-brand.co.uk](http://www.swan-brand.co.uk)



Scan this QR code  
to hear about  
our story



We love  
what we do



we're proud  
of our quality



Find us on Facebook

Copyright © Swan Products Ltd.  
PO Box 3117, Stoke-on-Trent ST4 9GD